

















CR1000/CR1400/CR8000 Configuration Guide

NOTE: The configuration change will take effect immediately and saved to memory.

<p>USB Keyboard Mode</p>  <p>M0002_01</p> <p>A1</p>	<p>Reset to USB Factory Defaults</p>  <p>M0001_02</p> <p>A2</p>	<p>Enable Motion Detection with Stand Detection, Start Delay 0 - Default</p>  <p>M0216_02</p> <p>A3</p>	<p>Disable Motion Detection with Stand Detection</p>  <p>M0217_02</p> <p>A4</p>
<p>Motion Detection On, Start Delay 0</p>  <p>M0161_03</p> <p>B1</p>	<p>Motion Detection On, Start Delay 500ms</p>  <p>M0162_03</p> <p>B2</p>	<p>Motion Detection On, Start Delay 0, Dark Environment</p>  <p>M0163_03</p> <p>B3</p>	<p>Motion Detection On, Start Delay 500ms, Dark Environment</p>  <p>M0164_03</p> <p>B4</p>
<p>Motion Detection Scanning Off</p>  <p>M0129_08</p> <p>C1</p>	<p>PDF417 On - Default</p>  <p>M0091_01</p> <p>C2</p>	<p>PDF417 Off</p>  <p>M0092_01</p> <p>C3</p>	<p>Intentionally Left Blank</p> <p>C4</p>
<p>QR Code On - Default</p>  <p>M0104_01</p> <p>D1</p>	<p>QR Code Off</p>  <p>M0105_01</p> <p>D2</p>	<p>Intentionally Left Blank</p> <p>D3</p>	<p>Intentionally Left Blank</p> <p>D4</p>
<p>Reader ID and Firmware Version</p>  <p>M0248_02</p> <p>E1</p>	<p>Cell Phone Reading Enhancement Enable</p>  <p>M0250_01</p> <p>E2</p>	<p>Cell Phone Reading Enhancement Disable</p>  <p>M0251_01</p> <p>E3</p>	<p>Intentionally Left Blank</p> <p>E4</p>
<p>F1</p>	<p>F2</p>	<p>F3</p>	<p>F4</p>